

PROSCALE "PRO-CELL 550g"

SPECIFICATION AND FUNCTION

1. Capacity: 550g / 0.1g
2. Over load: "O-LD"
3. Units: g, oz, ozt, dwt
4. Key function: ON/TARE, MODE
5. With Backlight
6. Low voltage: LCD displays "LO", please change the batteries.
7. Power: 2pcs CR2032 (6V) batteries

OPERATION

1. Place the scale on a level surface.
2. Press "ON/TARE" key to turn on the scale, until the LCD display shows "0.0", then press "MODE" key to choose the units.
3. Place an item on the tray, after stable you can read the weighing of the item.
4. Press "ON/TARE" key to turn off the scale.

CALIBRATION

1. Turn off the scale.
2. Press and hold the "MODE" and "ON/TARE" keys at the same time until the display shows numbers. Now release both keys.
3. Press the [ON/TARE] key one more time. The scale will display "200.0". Place the 200g calibration weight onto the platform. Now press the [ON/TARE] key one last time.
4. The LCD will show "PASS". Calibration is complete.

WARNING

1. "LO ": Low voltage, please replace the batteries.
2. "O-LD": Over load, please remove the item quickly to protect the scale.