

VERSA 77 Hanging Scale Manual

Please read complete instructions before use

Thank you for purchasing the Proscale Versa 77. With normal care and proper treatment the scale will provide years of reliable service. Please read all operating instructions carefully. Feel free to contact us at www.proscale.net

Please keep the following points in mind

Try to avoid lengthy exposure to extreme heat or cold

Allow for sufficient warm up time. Turn the scale ON and wait several seconds to give the internal components a chance to stabilize before weighing.

The cleaner the storage environment is the better. Long term exposure to dust, dirt, moisture, vibrations and the proximity to other electronic equipment can all cause adverse effect on the reliability and accuracy of the scale.

Handle with care. Gently apply all items to be weighed onto the hook. Although this scale is designed to be quite durable, try to avoid rough treatment as this may permanently damage the internal sensor and void your warranty.

Avoid shaking, dropping or otherwise shocking the scale. This is a precision instrument and **MUST BE HANDLED WITH EXTREME CARE.**

*** This scale is a precision instrument. Do not operate near an in-use cell phone, cordless phone, radio, computer or any other electronic device. These devices emit RF and can cause unstable readings. If your scale performs poorly, try moving the scale to a different room or location. This is a very precise scale- the display may seem to wander or jump when weighing. This is due to air currents or vibrations.

1.) Basic Features

- 1.) Capacity: 35KG/10G // 77LBS x 10Z
- 2.) Weighing Units: KG, LB, OZ
- 3.) HOLD feature
- 4.) Backlit Display
- 5.) Auto power off – 12 seconds if the scale has not been used(to conserve batteries)

2.) Operation

- 1.) ON key
 - A.) Press this key to turn on or turn off the scale
 - B.) If the scale is on press and hold the key to turn the scale off.
- 2.) Tare (Zero) key:
 - A.) Press this key to zero out a weight on the display (ie: weighing out a container)
- 3.) Unit key
 - A.) Press this key to change the weighing units (KG, LB, or OZ)
- 4.) Hold key
 - A.) Press this key to lock the weigh result for 60 seconds.

3.) Calibration

This scale has been calibrated by the factory and should not need user-recalibration. If you wish to recalibrate your scale please visit www.proscale.net for the advanced user calibration guide. Please note to calibrate you will need a 35KG weight.

Batteries

Two CR2032 lithium cell batteries (3V) are required

- 1.) To install batteries:
 - A.) Release the battery cover by sliding it outwards.
 - B.) Place the batteries into the battery compartment (align correctly). When replacing batteries use a tool if necessary to help facilitate removal and replacement.
 - C.) Replace battery cover.
 - D.) Scale is now ready for battery operation